



ENGLISH

Welcome to the MAGNAVOX family!

Dear MAGNAVOX family member:
Thank you for your confidence in MAGNAVOX. You've selected one of the best-built, best-backed products available today. We appreciate your support, and we'll do everything we can to keep you happy with your purchase for many years to come. After all, you're the reason we're in business!

As a MAGNAVOX family member, you're entitled to a world of special privileges - and our uncompromising commitment to your total satisfaction. Your MAGNAVOX product is protected by one of the most comprehensive warranties and outstanding service networks in the industry. What's more, your purchase qualifies you to receive advance information on exciting new products from MAGNAVOX, convenient access to our home shopping network for special products and accessories, plus factory-direct rebates and discounts on your future MAGNAVOX purchases.

All of this is our way of saying "thanks" for joining the MAGNAVOX family.

To start taking advantage of these great benefits, just remember to return your MAGNAVOX Owner's Registration Card.

Sincerely,
Robert Minkhorst
President and Chief Executive Officer

SAFETY INSTRUCTIONS - Read before operating equipment.

- This product was designed and manufactured to meet strict quality and safety standards. There are, however, some installation and operation precautions which you should be particularly aware of.
- Read Instructions** - All the safety and operating instructions should be read before the appliance is operated.
 - Retain Instructions** - The safety and operating instructions should be retained for future reference.
 - Heed Warnings** - All warnings on the appliance and in the operating instructions should be adhered to.
 - Follow Instructions** - All operating and use instructions should be followed.
 - Water and Moisture** - The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool, etc.
 - Carts and Stands** - The appliance should be used only with a cart or stand that is recommended by the manufacturer.
 - Wall or Ceiling Mounting** - The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
 - Ventilation** - The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
 - Heat** - The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
 - Power Sources** - The appliance should be connected to a power source only of the type described in the operating instructions or as marked on the appliance.
 - Power Cord Protection** - Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
 - Cleaning** - The appliance should be cleaned only as recommended by the manufacturer.
 - Power Lines** - An outdoor antenna should be located away from power lines.
 - Monuse Periods** - The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
 - Object and Liquid Entry** - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
 - Damaged or**
 - Power Requiring Service** - The appliance should be serviced by qualified service personnel when:
A. The power supply cord or the plug has been damaged;
B. Objects have fallen, or liquid has spilled into the appliance; or
C. The appliance has been exposed to rain; or
D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
E. The appliance has been dropped, or the enclosure damaged.
 - Servicing** - The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

Please follow these three important steps to get the most from your product.

- Return your Owner's registration card within 10 days**
- Know these safety symbols**
- Read the operation instructions carefully**

CAUTION: This bolt of lightning indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

This explanation point calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

The information in this manual can help you take full advantage of your product's many features, and ensure years of safe, reliable operation. So don't miss out. Read the enclosed instructions, safety tips and warranty information today.

THIS SET INCLUDES ...

- headphones (16-32 ohms/3.5 mm jack plug)
- AC power adapter SBC 6622 (Direct Current, plus-pole to the center pin)
- car accessory kit SBC 3557 Mk III, consisting of:
 - cassette adapter for transmitting sound through car radio
 - voltage converter (6V/500 mA Direct Current, plus-pole to the center pin) for power supply from the cigarette lighter jack (only for a 12V car battery, negative grounding)

PRECAUTIONS

Installation

- Do not expose the CD player, batteries or CDs to rain and dampness, sand and dust or to excessive heat caused by heating equipment, or to direct sunlight - for example inside a parked car.
- The lens may cloud over when the set is suddenly moved from cold to warm surroundings. Playing a CD is not possible then. Leave the CD player in a warm environment until the moisture evaporates.

Use your head when using headphones

- Hearing safety**
- Do not play your headset at a high volume. Hearing experts advise against continuous extended play.
 - If you experience a ringing in your ears, reduce the volume or discontinue use.

Traffic safety

- Do not use while driving a motorized vehicle. Using while driving may create a traffic hazard and is illegal in many areas.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations. Even if your headset is an open-air type designed to let you hear outside sounds, don't turn up the volume so high that you can't hear what's around you.

Maintenance

- The lens (X) of the CD player should never be touched! (see fig. 12)
- You can clean the CD player with a soft and slightly dampened chamois leather. Do not use any cleaning agents as they may have a corrosive effect.
- The mechanical parts of the CD player contain self-lubricating bearings and therefore must not be oiled or lubricated.
- Always pick up the CD by the edge and put it back in its box after use.
- To clean the CD, wipe it off in a straight line from the center toward the edge using a soft, lint-free cloth, see fig. 13. A cleaning agent may damage the disc!

WARNING	CAUTION
To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.	Use of controls or adjustments or performance of procedures other than specified herein may result in hazardous radiation exposure.

Instructions for Use

OPERATION

see figs. 1-7

PHONES CD-OUT	<ul style="list-style-type: none">connect the supplied headphones,or use this jack as output for CD reproduction through your HiFi system or car radio (in this case the volume of the CD player has to be set between 6 and 8)
OPEN	<ul style="list-style-type: none">press OPEN to open the lid of the CD playerinsert a CD with the label facing uppush gently on the CD's center so that it fits onto the hubclose the lid by pushing down on the left side of the lid until you hear it click
VOLUME	<ul style="list-style-type: none">adjust the volume
▶	<ul style="list-style-type: none">press ▶ to start CD play"SHUFFLE": during CD play press ▶ to play all tracks repeatedly in random order until you press ▶ again to go back to normal CD play
◀◀	<ul style="list-style-type: none">during CD play: press ◀◀ once/several times to select the beginning of the current/previous track(s)in STOP mode: press ◀◀ once/several times to select the beginning of the current/previous track(s), then press ▶ to start CD play"SEARCH" backward: during CD play, hold ◀◀ down to find a particular passage
▶▶	<ul style="list-style-type: none">during CD play: press ▶▶ once/several times to select the beginning of the next track(s)in STOP mode: press ▶▶ once/several times to select the beginning of the next track(s), then press ▶ to start CD play"SEARCH" forward: during CD play, hold ▶▶ down to find a particular passage
■	<ul style="list-style-type: none">press ■ to stop CD playpress ■ again to switch off the CD player
HOLD	<ul style="list-style-type: none">slide the switch to the right to deactivate all buttons (except OPEN)now the set is protected against accidentally touching the buttons when carrying the CD player around
DBB	<ul style="list-style-type: none">slide the switch to the right to increase the bass level

Display indication of - SHUFFLE and HOLD mode
- TOTAL TRACKS in STOP mode
- CURRENT TRACK during CD play

POWER SUPPLY

AC power adapter SBC 6622 (supplied)

see fig. 8

- Make sure that the local voltage corresponds to the voltage of the adapter (Direct Current, plus-pole to the center pin).
- Connect the adapter to the player's 6 V DC jack and to the wall jack.
- Always disconnect the AC power adapter if you don't use it.

Alkaline batteries, type R6, UM3 or AA-cells (optional)

see fig. 9

- Remove the battery holder (supplied) from the battery compartment and insert 4 alkaline batteries (type R6, UM3 or AA) according to the "+" and "-" indications in the battery holder.
- Replace the battery holder in the battery compartment. Playing time: approx. 10 hours.
- Remove the batteries if they are empty or the CD player won't be used for a long time.

IN-CAR USE

see figs. 10-11

Car accessory kit SBC 3557 Mk III (supplied)

- Find a good and safe place for the CD player on a horizontal, vibration-free and stable surface that is not dangerous or in the way of the driver or passengers.
- Connect the DC plug of the voltage converter to the 6 V DC jack of your CD player.
- Then insert the voltage converter into the cigarette lighter jack. If necessary, clean the cigarette lighter jack to obtain a good electrical contact.
- Turn down the volume and switch off the autoreverse function (if present) of your car radio cassette player.
- Connect the cassette adapter plug to the PHONES/CD-OUT jack of the CD player.
- Slide the cassette adapter carefully into the car radio cassette player.
- Make sure that the cord does not hinder your driving.
- Start the CD player, turn its volume between 6 and 8 and adjust the sound with the car radio controls.
- To remove the cassette adapter press the eject button of the car radio.
- Always remove the voltage converter when the CD player is not in use.

Notes:

- Do not remove the protective film from the metal head of the cassette adapter.
- If your car radio has a LINE IN jack, use it for the car radio connection instead of the cassette adapter. Connect a signal lead (optional) to this LINE IN jack and the PHONES/CD-OUT jack of the CD player.

TROUBLESHOOTING

If you are not able to remedy a problem by following these hints, consult your dealer or service facility. Under no circumstances should you try to repair the unit yourself, as this would invalidate the warranty.

Problem	Possible Cause	Remedy
No power	Batteries <ul style="list-style-type: none">Batteries are not in or are inserted wrongUse of new batteriesBatteries are emptyContact pins are dirty AC power adapter <ul style="list-style-type: none">Loose connection In-car use <ul style="list-style-type: none">Cigarette lighter is not powered when ignition is switched off	Batteries <ul style="list-style-type: none">Insert the batteries correctlyPress ▶Change the batteriesClean them with a soft, lint-free cloth AC power adapter <ul style="list-style-type: none">Connect the adapter securely In-car use <ul style="list-style-type: none">Insert batteries and disconnect the voltage converter
CD play does not start or interrupts	<ul style="list-style-type: none">The CD lid is not securely closedHOLD feature is activatedMoisture condensation <ul style="list-style-type: none">No CD or CD is incorrectly insertedThe CD is badly scratchedThe CD is dirty	<ul style="list-style-type: none">Close the lid securelySwitch off the HOLD featureLeave the CD player in a warm place until the moisture evaporatesInsert a CD with the label facing upUse another CDClean the CD with a soft lint-free cloth.
No sound or bad sound quality	<ul style="list-style-type: none">Loose or wrong connectionsVOLUME is not turned upHeadphones worn the wrong way <ul style="list-style-type: none">Headphone plug is dirtyStrong magnetic fields near the CD player In-car use <ul style="list-style-type: none">Strong vibrationsAdapter cassette is incorrectly insertedTemperature inside car is too high/hotCigarette lighter/jack is too dirtyWrong playback direction of the autoreverse function of the car cassette player	<ul style="list-style-type: none">Check connectionsAdjust the VOLUMEPay attention to the L (left) and R (right) indicationsClean the headphone plugChange position or connections In-car use <ul style="list-style-type: none">Find another place for the setInsert the adapter cassette correctlyLet the CD player adjust to the temperatureClean the cigarette lighter/jackChange the playback direction In-car use / use via HiFi system <ul style="list-style-type: none">Turn the player's VOLUME between 6 and 8 In-car use <ul style="list-style-type: none">Unfit car radio input jack In-car use <ul style="list-style-type: none">Use the cassette adapter

WARNING	CAUTION
To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.	Use of controls or adjustments or performance of procedures other than specified herein may result in hazardous radiation exposure.

FRANCAIS

Bienvenue dans la grande famille MAGNAVOX!

Cher client:
Nous vous remercions de faire confiance à MAGNAVOX. Vous avez choisi l'un des produits les mieux réalisés et les plus prisés actuellement disponible. Nous apprécions votre soutien et ferons tout possible pour que vous soyez satisfait de votre acquisition pour les années à venir. N'êtes-vous pas en effet notre raison d'être?

En qualité de membre de la famille MAGNAVOX, vous avez droit à des privilèges particuliers et à notre engagement sans réserve pour votre entière satisfaction. Votre appareil MAGNAVOX est protégé par l'une des garanties les plus étendues et par d'exceptionnels réseaux de service dans l'industrie. En outre votre achat vous autorise à recevoir en avant-première des informations sur les tout nouveaux produits MAGNAVOX, à avoir accès à notre réseau d'achat à domicile pour certains produits et accessoires, ainsi qu'à des rabais et remises d'usage sur vos futurs achats MAGNAVOX.

Ceci est notre manière de vous remercier d'avoir rejoint la famille MAGNAVOX. Pour commencer à bénéficier de ces nombreux avantages, n'oubliez pas de retourner votre carte d'immatriculation MAGNAVOX. Nous vous souhaitons beaucoup de satisfaction avec votre achat!

Meilleures salutations

Robert Minkhorst
Président-directeur général

CONSEILS DE SÉCURITÉ - À lire avant de faire marcher le matériel

Ce produit a été conçu et fabriqué en conformité avec des normes strictes de qualité et de sécurité. Il y a, cependant, certaines précautions d'installation et d'opération qu'il faut spécialement observer.

- Lisez les instructions** - Il faut lire toutes les instructions de sécurité et d'opération avant de faire marcher l'appareil.
- Gardez les instructions** - Il faut garder les instructions de sécurité et d'opération pour pouvoir s'y référer à l'avenir.
- Faites attention aux avertissements** - Il faut observer tous les avertissements collés à l'appareil et écrits dans le manuel d'instructions.
- Suivez bien les instructions** - Il faut suivre toutes les instructions d'opération et d'utilisation.
- Eau et humidité** - L'appareil ne devrait pas être utilisé près de l'eau (par exemple, près d'une baignoire, d'un lavabo, de l'évier, dans un sous-sol humide ou près d'une piscine).
- Chariots et supports** - Il faut utiliser cet appareil uniquement avec un chariot ou une table recommandée par le fabricant.
- Il faut déplacer un appareil et chariot avec soin. Un arrêt rapide, une force excessive et des sur faces inégales pourraient faire retourner l'appareil et le chariot.**
- Montage au mur ou au plafond** - Il faut monter l'appareil sur un mur ou plafond uniquement en suivant les recommandations du fabricant.
- Aération** - Il faut situer l'appareil de telle façon que son emplacement ou sa position ne gêne pas la bonne aération. Par exemple, il ne faut pas placer l'appareil sur un lit, un sofa, un tapis ou une autre surface pareille qui risque de boucher les ouvertures d'aération, ni l'installer dans une bibliothèque ou un coffret qui pourrait empêcher le flux d'air par les ouvertures d'aération.
- Chaleur** - Il faut situer l'appareil à l'écart des sources de chaleur telles que les radiateurs, les bouches de chaleur, les fours ou d'autres appareils ly compris les amplificateurs qui produisent de la chaleur.
- Protection du cordon d'alimentation** - Il faut faire passer les cordons d'alimentation de façon à éviter qu'on marche dessus ou que les objets placés sur eux ou contre eux les concentrent. Faire attention en particulier aux cordons et fiches et à l'endroit où ils sortent de l'appareil.
- Nettoyage** - Il faut nettoyer l'appareil uniquement de la façon recommandée par le fabricant.
- Lignes de transmission** - Il faut situer une antenne extérieure à l'écart des lignes de transmission d'électricité.
- Périodes d'inactivité** - Débranchez l'appareil lorsqu'il ne sera pas utilisé pendant une longue période de temps.
- Entrée des objets et des liquides** - Évitez de laisser tomber des objets ou des liquides par les ouvertures de l'enclos.
- Dommages qu'il faut faire réparer** - Il faut faire réparer l'appareil par un technicien qualifié lorsque:
A. Le cordon d'alimentation en électricité ou la fiche a été endommagé ou
B. On a laissé tomber des objets ou du liquide dans l'appareil ou
C. On a exposé l'appareil à la pluie ou
D. L'appareil ne paraît pas marcher normalement ou présente de grands changements d'opération ou
E. On a laissé tomber l'appareil ou endommager le coffret.
- Service après-vente** - L'utilisateur ne doit pas tenter de réparer l'appareil sans les réparations décrites dans les instructions d'opération. Toutes les autres réparations doivent être effectuées par un technicien qualifié.

Pour que ce produit vous donne le meilleur de lui-même, suivez les trois conseils ci-après

- Retournez dans les 10 jours la carte d'immatriculation**
- Connaissez les symboles de sécurité**
- Lisez avec soin les instructions d'utilisation**

AVOX MAIL

INSTRUCTIONS

ET ENSEMBLE COMPREND ...

- casque (16-32 ohms/fiche jack 3,5 mm)
- adaptateur secteur SBC 6622 (CC, pôle positif à la broche centrale)
- kit voiture SBC 3557 Mk III, comprenant:
 - une cassette adaptatrice pour la transmission du son dans votre autoradio
 - et un adaptateur à brancher sur la prise allume-cigare (uniquement dans le cas d'une batterie de voiture de 12 V, mise à la masse négative). Le convertisseur fournit un courant continu de 6 V/500 mA, pôle positif à la broche centrale

PRECAUTIONS

Installation

- N'exposez pas le lecteur de CD, les piles et les disques à la pluie, à l'humidité, au sable, à la poussière ou à une chaleur excessive provoquée par des appareils de chauffage ou par la lumière directe du soleil, par exemple à l'intérieur d'un véhicule garé en plein soleil.
- De la buée peut se former sur la lentille si le lecteur est transporté soudainement d'un endroit froid à un endroit plus chaud. Si cela se produit, il n'est pas possible d'écouter un disque. Laissez le lecteur de CD dans un endroit chauffé jusqu'à ce que l'humidité s'évapore.

En utilisant un casque

Protection de l'ouïe

- Ne mettez pas l'appareil à son volume maximum. Les experts en audition mettent en garde contre une écoute prolongée.
- Si vous entendez un bourdonnement dans les oreilles, diminuez le volume ou interrompez l'écoute.

Sécurité de la circulation

- N'utilisez pas le casque pendant que vous conduisez un véhicule. Cela pourrait constituer un danger pour la circulation et n'est pas autorisé dans de nombreux pays.
- Dans des situations potentiellement dangereuses, il est recommandé de prêter une attention particulière ou d'interrompre momentanément l'écoute.
- Même si votre casque est perméable aux bruits ambiants, ne portez pas le volume à un niveau tel qu'il vous empêcherait d'entendre ce qui se passe autour de vous.

Entretien général

- La lentille X ne doit pas être nettoyée (voir fig. 12).
- Vous pouvez nettoyer le lecteur de CD à l'aide d'une peau de chamois douce légèrement humidifiée. N'utilisez pas de produits de nettoyage car ils pourraient avoir un effet corrosif.
- Les éléments mécaniques du lecteur de CD sont équipés de paliers autolubrifiants qui ne doivent être de ce fait ni huilés ni lubrifiés.
- Manipulez toujours les disques par le bord et remettez-les toujours dans leur boîtier après usage.
- Pour nettoyer le CD, frottez en ligne droite du centre vers la périphérie, à l'aide d'un chiffon doux non pelucheux, voir fig. 13. Un agent de nettoyage peut endommager le disque!

L'appareil répond aux normes FCC, Part 15 et 21 CFR 1040.10.

AVIS	ATTENTION
Afin de réduire tout risque d'incendie ou de choc électrique, il ne faut pas exposer cet appareil à la pluie ou à l'humidité.	L'utilisation des commandes des réglages ou le non-respect des procédures ci-incluses peuvent se traduire par une exposition dangereuse à l'irradiation.

Mode d'emploi

FUNCTIONNEMENT

voir fig. 1 à 7

PHONES CD-OUT	<ul style="list-style-type: none">connectez le casque fourni,ou utilisez cette prise comme sortie pour la reproduction du CD par le biais du système HiFi ou par l'autoradio (dans ce cas, le volume du lecteur de CD doit être réglé entre 6 et 8)
OPEN	<ul style="list-style-type: none">appuyez sur cette touche pour ouvrir le couvercle du lecteur de CDinsérez un CD, l'étiquette dirigée vers le hautexercez une légère pression sur son centre afin qu'il s'adapte bien au moyeurefermez le couvercle en appuyant sur son côté gauche jusqu'à ce qu'il s'encliquette
VOLUME	<ul style="list-style-type: none">réglez le volume
▶	<ul style="list-style-type: none">appuyez sur ▶ afin de débiter la lecture du CD"SHUFFLE": pendant la lecture du CD, appuyez sur ▶ et toutes les plages seront sans cesse lues dans un ordre aléatoire jusqu'à ce que vous appuyiez à nouveau sur ▶ pour revenir à la lecture normale du CD
◀◀	<ul style="list-style-type: none">durant la lecture du CD: appuyez une fois/plusieurs fois sur ◀◀ afin de sélectionner le début de (des) plage(s) en cours/précédente(s)en mode STOP: appuyez d'abord une fois/plusieurs fois sur ◀◀ afin de sélectionner le début de (des) plage(s) en cours/précédente(s) et appuyez ensuite sur ▶ afin de débiter la lecture du CD"RECHERCHE" arrière: pendant la lecture du CD, maintenez enfoncée la touche ◀◀ afin de trouver un passage déterminé
▶▶	<ul style="list-style-type: none">durant la lecture du CD: appuyez une fois/plusieurs fois sur ▶▶ afin de sélectionner le début de (des) plage(s) suivante(s)en mode STOP: appuyez d'abord une fois/plusieurs fois sur ▶▶ afin de sélectionner le début de (des) plage(s) suivante(s) et appuyez ensuite sur ▶ afin de débiter la lecture du CD"RECHERCHE" avant: pendant la lecture du CD, maintenez enfoncée la touche ▶▶ afin de trouver un passage déterminé
■	<ul style="list-style-type: none">appuyez sur ■ afin d'interrompre la lecture du CDappuyez à nouveau sur ■ afin de mettre le lecteur de CD hors tension
HOLD	<ul style="list-style-type: none">Faites coulisser le commutateur vers la droite afin de neutraliser toutes les touches - à l'exception de OPEN: l'appareil est à présent protégé contre toute commande accidentelle des touches lorsque vous emportez le lecteur de CD
DBB	<ul style="list-style-type: none">Faites coulisser le commutateur vers la droite afin d'augmenter le niveau des graves

Indication de l'afficheur: - mode SHUFFLE (lecture aléatoire) et HOLD (verrouillage)
- toutes les plages en mode STOP
- plage en cours pendant la lecture du CD

ALIMENTATION

Adaptateur secteur SBC 6622 (fourni)

voir fig. 8

- Assurez-vous que la tension locale correspond à celle de l'adaptateur (CC, pôle positif à la broche centrale).
- Connectez l'adaptateur à la prise 6 V CC du lecteur et à la prise murale.
- Débranchez toujours l'adaptateur secteur CA si vous ne l'utilisez pas.

Piles alcalines, type R6, UM3 ou AA (en option)

voir fig. 9

- Retirez le support pour piles (fourni) du compartiment pour piles et insérez-y 4 piles alcalines de type R6, UM3 ou AA). Respectez les indications de polarité "+" et "-" figurant dans le support pour piles.
- Remettez le support pour piles en place dans le compartiment prévu à cet effet.
- Durée de lecture: environ 10 heures.
- Retirez les piles si elles sont arrivées à épuisement ou si le lecteur de CD ne doit pas être utilisé pendant longtemps.

UTILISATION EN VOITURE

voir fig. 10 à 11

Kit d'utilisation en voiture SBC 3557 Mk III (fourni)

- Choisissez un endroit approprié et sûr pour le lecteur de CD, sur une surface horizontale, stable et sans vibrations, de manière à ce qu'il ne présente aucun danger pour le conducteur ou les passagers et qu'il ne les gêne pas (voir également le paragraphe "Accessoires").
- Brancher la fiche CC du convertisseur de tension sur la prise 6 V DC du lecteur de CD.
- Insérer ensuite le convertisseur de tension dans la prise allume-cigare. Si nécessaire, nettoyez la prise allume-cigare afin d'obtenir un bon contact électrique.
- Baissez le volume et neutralisez la fonction autoreverse (si l'appareil en est doté) du lecteur de cassettes du véhicule.
- Brancher la fiche de la cassette adaptatrice à la prise PHONES/CD-OUT du lecteur de CD.
- Introduisez avec précaution la cassette dans le lecteur de cassettes du véhicule.
- Faites attention à ce que le lecteur ne soit pas incommode pas lorsque vous conduisez.
- Débuter la lecture du CD, mettez le volume entre 6 et 8 en le réglant à l'aide des touches de l'autoradio.
- Pour retirer la cassette, appuyez sur la touche d'éjection du lecteur de cassettes.
- Retirez toujours le convertisseur de tension lorsque le lecteur de CD n'est pas utilisé.

Remarques:

- N'enlevez pas la couche protectrice de la tête en métal de la cassette adaptatrice.
- Si votre autoradio est doté de la prise LINE IN (entrée de ligne), il est recommandé de l'utiliser pour le branchement au lieu de la cassette adaptatrice. Connecter un câble de signal en